



SET UP GUIDE

1. Make sure your desired power point (10A outlet) is in the “on” position
2. While holding the reset button on the PWRON plug, insert into power point and continue pressing for 5 seconds (a slow red “pulse” will occur)
3. Using laptop/desktop/tablet or smartphone find “pwron device” in your wifi connection list and select it
4. Now open your internet browser and type the following address 192.168.4.1 (for best results use Google Chrome)
5. Follow the screen prompts on your laptop/desktop/tablet or smartphone to set up your PWRON device.
6. Have your wifi name and password handy for set up.

NOTES:

1. You can change to other powerpoints (10A outlets) after set up if needed – every time you set your plug to a new wi-fi connection however, you will need to follow all set up steps.
2. Repeat step 2 if PWRON Device doesn’t show up in your wifi connection list.
3. When you connect to PWRON Device and type in 192.168.4.1 in your browser, you are now connected to the PWRON Device (not actually on the internet, although you are using your browser) – when you follow the on screen prompts you will be directed back to the internet, you can manually connect if automatic redirect takes too long,
4. To access your account, after initial set up – head to app.pwron.com.au and enter your account details